



ETB9643



## Quick Setup Guide

This guide will help you know your new tablet. For additional information please open the build-in instruction manual application in your tablet software or visit [www.morris.gr](http://www.morris.gr)


### Packing list

The following articles are included in your packing box of your new tablet PC:

- Tablet PC (MID)
- A/C charger
- OTG USB cable (for connecting accessories to tablet)
- USB cable (for connection with PC)
- Warranty card
- Quick Setup Guide

Note: Actual accessories provided with the product may vary.

### Connections and Buttons



### Battery charging

Before using the tablet for the first time, the battery must be charged. Use A/C charger provided to charge the tablet. In order to guarantee full battery, please charge for over 4 hours.

### Starting up


Press the power key for 5-6 seconds, until you can see the start up picture, unlock according to direction indication of lock icon on the interface. At first start up, a quick start guide will help you with basic settings.

### Turning off

Press and keep pressing the power key until the shutdown option pop up. Touch Power off. Touch OK.

### Main interface

1. Back icon
2. Home Icon
3. Recent Apps
4. Volume buttons
5. Menu Icon
6. Notifications bar
7. Status bar



### Pull down menu

Touch and drag downwards the notifications bar if there is a notification icon on the top left corner. Touch and drag downwards the status bar to reveal quick settings menu.



### Standby Mode

After a specific time limit without use, the tablet will go in standby mode and shut the screen off, so as to save battery power. Press the power key once and the screen will go off standby and you can unlock your tablet. Under normal mode, press the power key once and the tablet will go to standby mode immediately. You can set the time limit before auto standby in settings/display.

### Virtual keyboard input

1. Displays the typed text
2. Switch between uppercase and lowercase
3. Choose numbers / symbols / letters
4. Change input language
5. Space bar (long press to select between languages) and Android3 input options
6. Enter button
7. Backspace button



### Selecting Language

To change the display language, go to settings/Language & input/Language and select the desired language from the list. In the same settings page you can alter the default keyboard layout (input options).



### Basic settings

Long press on any empty space of the screen to show options menu with Wallpaper, Widgets, Settings shortcuts.

### Connection to PC

Use the USB cable to connect tablet to a PC. There will be a notification in the status bar of tablet that USB has been connected. Touch the USB Connected notification. Touch the "Turn on USB storage" button on screen and now you can handle tablet storage space as separate disc drive in your PC.



### WiFi Connection

Enter the settings menu and turn on the Wi-Fi function if it is turned off. After a little while all available Wi-Fi networks will be listed. Touch the Wi-Fi you want to connect to and if it asks for a password, type it. Enter any other required settings if needed and touch "Connect". The network will be saved, so next time it is in range your tablet will connect automatically.

### Frequently Asked Questions

Tablet feels very hot

Too many applications open. Try closing some. If you are charging the tablet then it is normal to get hot. If running application for long time with display on, then it is normal.

Tablet runs very slow

Too many applications open. Try closing some. If you just used factory reset or upgraded the OS, it needs some time to install all pre-installed apps. If you set automatic updates to on then it might be downloading and installing updates for your apps.

Cannot connect to Wi-Fi network

Ensure your wireless router is on and working. Ensure that you are within range of the network. Ensure that you typed the correct password and other settings like security type.

System crashes often

Third party applications may have become unstable. Press Reset button to restart. If problem persist you may have to reset to factory defaults.

