

# F&U – FL20102 LED TV

## ΟΔΗΓΙΕΣ ΠΡΩΤΗΣ ΕΓΚΑΤΑΣΤΑΣΗΣ – QUICK START GUIDE

### **ΕΛΛΗΝΙΚΑ**

Η τηλεόραση σας έχει την δυνατότητα να εμφανίζει στο άνω αριστερό μέρος της οθόνης εικονίδια με τα χαρακτηριστικά της, όταν βρίσκεται σε λειτουργία ΚΑΤΑΣΤΗΜΑΤΟΣ. Προκειμένου να τα αφαιρέσετε και να μεταβείτε σε λειτουργία ΟΙΚΙΑΣ θα πρέπει να ακολουθήσετε τα ακόλουθα βήματα:

*A. Στην αρχική εγκατάσταση:*

- Στην ΤΟΠΟΘΕΣΙΑ επιλέξτε ΟΙΚΙΑ

*B. Σε περίπτωση που έχετε κάνει ήδη την αρχική εγκατάσταση σε τοποθεσία ΚΑΤΑΣΤΗΜΑ*

1. Πιέστε το πλήκτρο MENU στο χειριστήριο
2. Μεταβείτε στην επιλογή: ΡΥΘΜΙΣΕΙΣ
3. Επιλέξτε: ΤΟΠΟΘΕΣΙΑ
4. Ορίστε σε: ΟΙΚΙΑ

### **ENGLISH**

Your TV set supports the feature of displaying on the left upper side of the screen logos with your TV set's specifications, in case that it is set in STORE mode. In order to remove them and revert to HOME mode you should follow the following simple steps:

*A. During the initial installation:*

- At LOCATION select HOME

*B. In case you have completed the initial installation and set the unit at STORE mode:*

1. Press the MENU button on the remote
2. Go to menu: SETUP
3. Select: LOCATION
4. Set to: HOME