

UNITED[®]

2-in-1 DESKTOP FAN INSTRUCTIONS MANUAL



Model:UDF-628

Pls read these instructions carefully before using

Note: These instructions must be read fully before commencing assembly/use of the fan. Retain these instructions for future reference.

FOR HOUSEHOLD USE ONLY

Assembly

- 1) Do not plug in the power cord until the fan is assembled and securely positioned.
- 2) Attach the body of the fan to the clip using the screw and nut provided. Do not over-tighten.

Operating instructions

- 1) Attach the fan to a stable pole, shelf or similar using the clip. Alternatively the fan can be wall-mounted using the screw holes in the base of the clip (screws not provided).
- 2) Do not place the fan close to an open window. Rain splashing onto the fan could cause an electric shock hazard.
- 3) Plug the power cord into a suitable socket.
- 4) Switch on the fan using the power switch on the rear of the body. There are two speeds indicated by 1 (low) and 2 (high).
- 5) The fan can be rotated into several click positions, and tilted up/down using the screw knob to tighten as necessary.

CAUTION:

- 1) Do not use the fan if the power cord or plug is damaged. If the power cord or plug is damaged it must be replaced by a recognized service agent or other qualified person.
- 2) Never insert fingers, pencils or any other objects into the grid when the fan is running.
- 3) Unplug the fan from the power socket when moving it from one location to another.
- 4) Unplug the fan from the power socket when cleaning.
- 5) This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Cleaning

1. Ensure that the fan is unplugged from the power socket before commencing cleaning.
2. The wire front cage may be removed for cleaning by gently easing each clip away from the wire rim in turn. Do not disassemble other parts of the fan.
RE-FIT THE WIRE CAGE BEFORE USING THE FAN.
3. Plastic parts should be cleaned with a mild detergent and a damp cloth or sponge. Ensure that **all** traces of the detergent are removed with the damp cloth or sponge.
4. **Care should be taken to ensure that water (or other liquid) does not enter the motor housing.**
5. Do not use spray cleaners.
6. Never use solvent or abrasive cleaners.

Warranty

This product has been made under strictest quality control procedures to ensure good performance and reliability. The product is guaranteed against defects in materials and workmanship for a period of 12 months from the date of purchase, subject to:

1. Please retain your receipt as proof of purchase, as this will be required in the event of a warranty claim.
2. The warranty is valid only if the product has been used solely for domestic purposes and in accordance with the instructions provided.
3. The warranty is invalid if:
 - a. the product has been connected to an unsuitable electricity supply;
 - b. the product has been dismantled or interfered with in any way or damaged through misuse;
 - c. the product has been damaged by lightning strike, mains power surge or water ingress.
4. We undertake to repair or replace (at our discretion) free of charge any part found to be defective.
5. The warranty does not cover accidental damage, normal wear and tear, or consequential loss of any kind.

Nothing in this warranty excludes, restricts or otherwise affects your statutory rights.

In line with our policy of continuous improvement, we reserve the right to make alterations and improvements to this product, packaging and documentation.

NOTICE ABOUT RECYCLING



Your product is designed and manufactured with high quality materials and components which can be recycled and reused.

This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from your household waste. Please dispose of this equipment at your local community waste collection/ recycling centre.

In the European Union there are separate collection systems for used electrical and electronic products. Please help us to conserve the environment we live in!

DECLARATION OF CONFORMITY

This product complies with the requirements of Directives:

EMC Directive: 2004/108/EC

Low Voltage Directive: 2006/95/EEC

Rohs Directive: 2011/65/EU

The above directives declare that this model is in compliance

with following norms:

EN 55014-1: 2006+A1

EN 55014-2: 1997+A1+A2

EN 61000-3-2: 2006+A1+A2

EN 61000-3-3: 2008

EN 60335-2-80: 2003+A1: 2004+A2: 2009

EN 60335-1: 2002+A1: 2004+A2: 2006+A11: 2004+A12: 2006+A13: 2008

EN 62233: 2008

EXCLUSIVE DISTRIBUTOR

Amiridis - Savvidis S.A.

- 33, Vas. Olgas str - P.C. 54641 - Thessaloniki
Tel: 2310-850107, 2310-850108, Fax: 2310-867835
- 45, Posidonos str - P.C. 18344 - Moschato
Tel: 210-9402064, Fax: 210-9402137