

UNITED®

FAN HEATER

MODEL: UHF-847



USER INSTRUCTIONS

WARNING

While using any electrical appliance specific precautions must be followed. Read the instructions carefully and keep them for further reference

This product is only suitable for well insulated spaces or occasional use.

IMPORTANT SAFEGUARDS

When using any electrical appliance basic precautions should be followed. Please read the following instructions as they are for your benefit and safety:

1. Make sure the power supply used corresponds to the rating label.
2. Never obstruct or block any openings of the heater.
3. Use the heater only on a flat surface.
4. Always disconnect the appliance from the main power supply when not in use and when cleaning.
5. Do not leave the heater "ON" unattended.
6. Never cover the heater as this may lead to risk of fire.
7. Keep the appliance a distance of at least 90 cm from any combustible material such as furniture, curtains, bedding, clothes or papers.
8. Do not use this heater in the immediate surrounding of a bath, a shower or a swimming pool.
9. Do not immerse the heater in water or allow for water to come into contact with the plug or control device.
10. Keep this heater clean. Do not allow objects to enter the ventilation opening as this may cause electric shock, fire or damage to the heater.
11. Close supervision is required when any appliance is used near or by children.
12. Never allow the cord to touch wet or hot surfaces, become twisted or be within the reach of children.
13. Do not use outdoors
14. Do not place on or near a hot gas electric burner.
15. If the supply cord is damaged, it must be replaced the manufacture or its service agent or a similarly qualified person must replace it in order to avoid a hazard.
16. Do not use the appliance for other than its

intended use as described in this instruction book.


17. Do not place the heater immediately below a socket outlet.
18. This appliance is intended for household use only.
19. Do not leave the heater on overnight.
20. While cleaning, make sure not to use a wet cloth or use water on any part of the unit, as this may cause a short circuit or electrical shock.
21. Do not use this unit in any area where water present.
22. Make sure the power cord is placed at the back away from the front panel of the heater.
23. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
24. Children should be supervised to ensure that they do not play with the appliance.
25. Caution: Do not cover anything on your heater when in use.
26. The fan-heater must not be placed near a socket and the following hint: This fan-heater must not be used near a bath, shower or swimming-pool
27. Children of less than 3 years should be kept away unless continuously supervised. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

28.

NOTE: Should the unit overheat, this heater is fitted with a safety with overheating device which will switch the off automatically. (If the air vent is blocked or if the fan function is not blowing air). If this should happen, all you need to do this:

Disconnect the plug from the electrical socket for a few minutes. Ensure the heater is not covered and nothing is obstructing any of the vents. Plug the heater back into the electrical socket and switch the heater back ON.

HOW TO OPERATE

1. Remove the unit from the box and take off any protective wrapping.
2. Place the heater on a smooth level surface and least 30cm away from any obstacles.
3. Plug your fan heater into the power supply. Make sure your power supply corresponds to the power indicated on the rating label.
4. Turn the thermostat knob (right) in a clockwise direction until it reaches the maximum setting.
 - Summer service (ventilation only): turn the knob to setting 
 - Heating at reduced power: turn the knob (right) to setting I (1000W).
 - Heating at full power: turn the (right) to setting II (2000W).
 - Switching off: turn the knob (left) to setting O
 - To use the oscillation function press the button on the base of the unit. The appliance will start rotating left and right.
5. When the room has reached the required temperature turn the right thermostat knob (where included). In an anti-clockwise direction up to the point where the appliance switches off and not beyond. The temperature fixed in this way will be automatically regulated and kept at a constant level by the thermostat.

OVERHEATING SAFETY DEVICE

Your heater is fitted with a safety device that switches off the heater in the event of overheating.

Should the heater stop working, turn the heater off and inspect of blockage of inlet or outlet. Wait at least 5 minutes of the protection system to reset before attempting to restart the heater. If the heater fails to operate the safety device switches the heater off again, return the heater to your nearest service center for examination or repair.

CLEANING YOUR FAN HEATER

1. Always disconnect the appliance from the main supply before cleaning.
2. Clean the outside of the heater by wiping with damp cloth and guff with a dry cloth.
3. Do not use Benzine or any other detergents/solvents or chemical agents to clean the heater.

SERVICE

Hints before returning the appliance:

Is your household socket working properly?

Are all required switches in the “ON” position?

Ensure that the plug is firmly in the socket and switched on.

Ensure the heater is standing on an even surface.

NOTE: If the power supply cord, or plug is damaged, an Amalgamated Appliance service center or an official agent must replace it.

If service becomes necessary with the warranty period the appliance should be returned to an approved service center. Servicing outside the warranty period is still available, however it will be chargeable.

Model identifier(s):	UHF-847		
Item	Symbol	Value	Unit
Heat output			
Nominal heat out-put	P_{nom}	1.8-2	kW
Minimum heat output (indicative)	P_{min}	0.015	kW
Maximum continuous heat output	$P_{max,c}$	2	kW
Auxiliary electricity consumption			
At nominal heatoutput	el_{max}	0	kW
At minimum heatoutput	el_{min}	0	kW
In standby mode	el_{SB}	0	kW
Type of heat input, for electric storage local space heaters only (single select)			
manual heat charge control, with integrated thermostat	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
manual heat charge control with room and/or outdoor temperature feedback	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
electronic heat charge control with room and/or outdoor temperature feedback	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
fan assisted heat output	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
Type of heat output/room temperature control (single select)			
single stage heat output and no room temperature control	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
Two or more manual stages, no room temperature control	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
with mechanic thermostat room temperature control	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No		
with electronic room temperature control	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
electronic room temperature control plus day timer	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
electronic room temperature control plus week timer	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
Other control options (multiple selections possible)			
room temperature control, with presence detection	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
room temperature control, with open window detection	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
with distance control option	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
with adaptive start control	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
with working time limitation	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
with black bulb sensor	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No		
Contact details	Kalliopi Karyda & CO LP 87A, 17is Noemvriou str, P.C. 55535 Pylea, Greece T: +302316006600, F: +302316006650		

NOTICE ABOUT RECYCLING



Your product is designed and manufactured with high quality materials and components which can be recycled and reused.

This symbol means that electrical and electronic equipment, at their end-of-life,

should be disposed of separately from your household waste. Please dispose of this equipment at your local community waste collection/ recycling centre.

In the European Union there are separate collection systems for used electrical and electronic products.

Please help us to conserve the environment we live in!

DECLARATION OF CONFORMITY

Herewith, Kalliopi Karyda & Co, LP. states that this product, complies with the requirements of below directives:

EMC-Directive: 14 / 30 / EU

Low Voltage Directive: 14/ 35 / EU

ErP Directive 09 / 125 / EC

CE Marking Directive: 93 / 68 / EEC

RoHS Delegated Directive 15/863/EU

The detailed declaration of conformity can be found at www.united-electronics.gr



Exclusive importer in Greece:

Kalliopi Karyda & Co LP.

87A, 17is Noemvriou str, P.C. 55535

Thessaloniki – Greece

T: +302316006600 | F: +302316006650

www.united-electronics.gr