

UNITED®

INSTRUCTIONS MANUAL

MICA PANEL

Model: UHM-880




This product is only suitable for well insulated spaces or occasional use.

Please read this instruction manual carefully before operation!

Keep in a safe place for future reference.

I . Product Appearance



II . Main Technical Date

| Model | Rated Voltage | Rated Frequency | Rated Power |
|---------|---------------|-----------------|-------------|
| UHM-880 | 220-240V | 50Hz | 2000W |

III .Precaution Items For Safe Use

- Please read the product manual carefully before using the heater.
- Insert the plug into the socket (requirements for socket and power cord: AC 220-240V, 50/60Hz, $\geq 10A$). The heater must not be located below a fixed socket.
- Please operate according to the instructions of the manual. Any unrecompensed operation can cause fire, short circuit and personal injuries.
- Ensure the appliance is switched off before connecting to the mains power supply.
- In order to prevent short circuit, fire or damages to the appliance, never insert any article into the heater or block the cooling net.
- Do not leave this appliance unattended when it's in use.

- Since the heater can generate heat, do not touch the hot surface with uncovered human body to prevent burns. Grab the plastic handle at the rear to move the heater when necessary. In case that children, animals or lame people and people lacking self-discipline are on the spot and left unattended, avoid using the appliance.
- Never use the heater outdoors.
- Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- Do not use the appliance in area where gasoline, paint and flammable liquid are used to stored.
- Never cover anything on the heater during use.
- To avoid current overload, do not share the use of a single socket with other appliances.
- The most common cause of overheating is deposits of dust or fluff in the appliance. Ensure these deposits are removed regularly by disconnect the appliance and vacuum cleaning air vents and grilles.
- Always ensure that hands are dry before operating or adjusting any switch on the product or touching the plug and socket-outlet.
- Switch off the power supply and disconnect from mains supply when not in use, before cleaning or other maintenance.
- When in use, keep the distance between window or wall at least 50cm.
- In case of product failure, please contact after-sales service agent for inspection and repairing. Unauthorized disassembling and replacement of parts are not allowed.
- If the power cord is damaged, it must be replaced by the manufacturer or its maintenance agent or a similarly qualified person in order to avoid potential hazards.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.


Children under 3 years of age should not be near the appliance unless they are constantly supervised. Children over the age of 3 and under the age of 8 are allowed to activate/deactivate the device, provided that it has been installed in its place of operation and that they have been given and fully understood specific instructions regarding the operation and dangers of the device, or are constantly supervised by an adult. Children from 3 to 8 years old are not allowed to connect the device to the power supply, adjust it, clean it or maintain it.

Technical Specifications:

| | |
|------------------------|--------------|
| Model | UHM-880 |
| Rated Voltage | 220 V -240V~ |
| Rated Frequency | 50-60 Hz |
| Rated Power | 2000W |

Assembly

1. Insert the wheels into the bottom part of the supporting feet and make sure it is tight enough.
2. Put the appliance with upside down, fix the to the appliance with screw



Utilization:

- Connect the appliance to safety socket.
- Turn on switch to the heating position (I or II)
- The heating functions(II)

| | |
|-----------------|-------|
| Heat setting I | 1000W |
| Heat setting II | 2000W |

- Turn the thermostat knob clockwise until reaching the maximum temperature.
- Once the room temperature is reached, slowly turn the thermostat knob anticlockwise until you get your required temperature.
- Turn the switch to “0” position to switch off the heater. and unplug the appliance.

Overheat safety device

- Your heater is fitted with a safety device which switches off the heater in the event of overheating. If the safety device operated, please turn the heater off, unplug the appliance and let it completely cool; then inspect for blockage of air inlet or outlet and attempt to restart the heater then after.
- If the heater fails to operate or the safety device switches the heater off again, return heater to your nearest service center for examination or repair.

Maintenance:

1. Always disconnect the appliance and let it completely cool before any maintenance.
2. Use a vacuum cleaner to remove dust from grilles.
3. Clean the outside of the unit with a damp cloth and then dry it with a dry cloth. Never immerse the unit in water, nor let water drip into the unit.

Storing:

1. Always disconnect the appliance, let it completely cool and clean it before storing.
2. If you do not use the device for a long period, put back the unit and the instruction manual to the original carton and store in a dry and ventilated place.
3. Do not place any heavy items on top of carton during storing as this may damage the appliance.

Model identifier(s): **UHM-880**

| Item | Symbol | Value | Unit | Item | Unit |
|--|--|-------|------|---|------|
| Heat output | | | | Type of heat input, for electric storage local space heaters only (select one) | |
| Nominal heat output | P _{nom} | 2.0 | kW | manual heat charge control, with integrated thermostat | No |
| Minimum heat output (indicative) | P _{min} | - | kW | manual heat charge control with room and/or outdoor temperature feedback | No |
| Maximum continuous heat output | P _{max,c} | 2.0 | kW | electronic heat charge control with room and/or outdoor temperature feedback | No |
| Auxiliary electricity consumption | | | | fan assisted heat output | |
| At nominal heat output | e _{lmax} | 0.000 | kW | Type of heat output/room temperature control (select one) | |
| At minimum heat output | e _{lmin} | 0.000 | kW | single stage heat output and no room temperature control | No |
| In standby mode | e _{lSB} | - | kW | Two or more manual stages, no room temperature control | No |
| | | | | with mechanic thermostat room temperature control | Yes |
| | | | | with electronic room temperature control | No |
| | | | | electronic room temperature control plus day timer | No |
| | | | | electronic room temperature control plus week timer | No |
| | | | | Other control options (multiple selections possible) | |
| | | | | room temperature control, with presence detection | No |
| | | | | room temperature control, with open window detection | No |
| | | | | with distance control option | No |
| | | | | with adaptive start control | No |
| | | | | with working time limitation | No |
| | | | | with black bulb sensor | No |
| Contact details | Kalliopi Karyda&Co LP 87A,17is Noemvriou str,P.C.55535 Pylea-Greece T:+302316006600 F:+302316006650 | | | | |

NOTICE ABOUT RECYCLING



Your product is designed and manufactured with high quality materials and components which can be recycled and reused.

This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from your household waste.

Please dispose of this equipment at your local community waste collection/recycling centre. In the European Union there are separate collection systems for used electrical and electronic products.

Please help us to conserve the environment we live in!

DECLARATION OF CONFORMITY

Herewith, Kalliopi Karyda & Co., LP. states that this product, complies with the requirements of below directives:

EMC-Directive: 14 / 30 / EU

Low Voltage Directive: 14 / 35 / EU

ErP Directive 09 / 125 / EC

CE Marking: 93 / 68 / EEC

RoHS Directive: 11 / 65 / EU & 15 / 863 / EU

The detailed declaration of conformity can be found at:

www.united-electronics.gr



Kalliopi Karyda & Co LP

87A, 17is Noemvriou str, P.C. 55535

Thessaloniki – Greece

T: +302316006600 | F: +302316006650